


THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-GSXR125-L8-1-GBR / Secondary Clutch Cover Part No. EC-GSXR125-L8-2-GBR /


SECONDARY ALTERNATOR COVER PART NO. EC-GSXR125-L8-1-GBR

- 1 Remove the fairing.
- 2 Remove 4 existing bolts from the Stock Alternator cover, shown as position Bolt 1, 2, 3 & 4
- 3 Place the Secondary Alternator Cover over the Stock cover.
- 4 Assemble 4 replacement bolts loosely in the correct position as shown.
- 5 Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**
- 6 Replace the fairing.



SECONDARY CLUTCH COVER PART NO. EC-GSXR125-L8-2-GBR

- 1 Remove the fairing.
- 2 Remove 3 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2 & 3.
- 3 Place the Secondary Clutch Cover over the stock cover.
- 4 Assemble 3 replacement bolts loosely in the correct position as shown.
- 5 Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**
- 6 Replace the fairing.



ENGINE COVER SET Part No. EC-GSXR125-2018-SET-GBR

Secondary Alternator Part No. EC-GSXR125-L8-1-GBR, Secondary Clutch Cover Part No. EC-GSXR125-L8-2-GBR