



**THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:**

Secondary Alternator Cover Part No. EC-CBR1000-2017-1-GBR / Secondary Clutch Cover Part No. EC-CBR1000-2017-2-GBR /  
Secondary Pulse Cover Part No. EC-CBR1000-2017-3-GBR


**SECONDARY ALTERNATOR COVER**  
**PART NO. EC-CBR1000-2017-1-GBR**

1. Remove original fairing panel and plastic cover that is fitted over the original alternator cover.
2. Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
3. Place the Secondary Alternator Cover over the stock cover.
4. Assemble 4 replacement bolts (**M6X35HHF**) loosely in the correct position as shown.
5. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**
6. Replace original plastic cover and fairing.




**SECONDARY CLUTCH COVER**  
**PART NO. EC-CBR1000-2017-2-GBR**

1. Remove fairing.
2. Remove 3 existing bolts from the stock Clutch cover, shown as position Bolt 1, 2 & 3.
3. Place the Secondary Clutch Cover over the stock cover.
4. Loosely assemble bolt 3 first (2-3 turns), then bolts 1 & 2, with the replacement bolts supplied (**M6X35HHF**).
5. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations. **DO NOT OVERTIGHTEN.**
6. Replace fairing.



**SECONDARY PULSE COVER**  
**PART NO. EC-CBR1000-2017-3-GBR**

1. Remove offside fairing infill panel.
2. Remove 4 existing bolts from the stock Pulse cover, shown as position Bolt 1, 2, 3 & 4. *Note: Bolt 1 has a sealing washer that needs retaining for re-use later.*
3. Place the supplied M6WCU copper washer over 1 off M6X35HHF (Hex Head Flanged) bolt and then mount this bolt through Bolt Position 1 of the moulded alternator cover. Place the original OEM washer back over the threaded end of this bolt. (As illustrated in **Fig 1**).
4. Place the Secondary Pulse Cover over the OEM stock cover.
5. Assemble the remaining 3 replacement bolts loosely in the correct position as shown.
6. Tighten bolts to a Torque of 10Nm as per Manufacturer's recommendations.
7. Refit offside fairing infill panel.



**SET PART No: EC-CBR1000-2017-SET-GBR:** EC-CBR1000-2017-1-GBR / EC-CBR1000-2017-2-GBR / EC-CBR1000-2017-3-GBR