


THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-Z900-2017-1-GBR / Secondary Clutch Cover Part No. EC-Z900-2017-2-GBR


Secondary Pulse Cover Part No. EC-Z900-2017-3-GBR / Bullet Frame Sliders STREET Part Nos. FS-Z900-2017-LHS-S / FS-Z900-2017-RHS-S

SECONDARY ALTERNATOR COVER PART NO. EC-Z900-2017-1-GBR

1. Remove 4 existing bolts from the stock Alternator cover, shown as position Bolt 1, 2, 3 & 4.
2. Place the Secondary Alternator Cover over the stock cover. *Please Note: Do not remove fairing bracket as GBRacing Secondary Cover will fit over it.*
3. Assemble 4 replacement bolts loosely in the correct positions as shown.
4. Tighten bolts to a Torque of 11Nm as per Manufacturer's recommendations.
DO NOT OVERTIGHTEN.



Bolt 1
M6X35HHF -
11Nm




Bolt 4
M6X40HHF -
11Nm

Bolt 2
M6X35HHF -
11Nm


Bolt 3
M6X35HHF - 11Nm

SECONDARY CLUTCH COVER PART NO. EC-Z900-2017-2-GBR

1. Remove 4 existing bolts from the Clutch cover, shown as position Bolt 1, 2, 3 & 4.
2. Place the Secondary Clutch Cover over the stock cover.
3. Assemble 4 replacement bolts loosely in the correct position as shown.
4. Tighten bolts to a Torque of 11Nm as per Manufacturer's recommendations.
DO NOT OVERTIGHTEN.



Bolt 1
M6X40HHF -
11Nm




Bolt 2
M6X40HHF -
11Nm

Bolt 4
M6X35HHF -
11Nm

Bolt 3
M6X40HHF -
11Nm

SECONDARY PULSE COVER PART NO. EC-Z900-2017-3-GBR

1. Remove 4 existing bolts from the Pulse cover, shown as position Bolt 1, 2, 3 & 4.
2. Place the Secondary Pulse Cover over the stock cover. Assemble 4 replacement bolts loosely in the correct position as shown.
3. Tighten bolts to a Torque of 11Nm as per Manufacturer's recommendations.
DO NOT OVERTIGHTEN.



Bolt 1
M6X35HHF -
11Nm



Bolt 4
M6X35HHF -
11Nm

Bolt 2
M6X35HHF -
11Nm

Bolt 3
M6X35HHF - 11Nm

Engine Cover Set: EC-Z900-2017-SET-GBR


EC-Z900-2017-1-GBR, EC-Z900-2017-2-GBR, EC-Z900-2017-3-GBR

BULLET FRAME SLIDER - LEFT HAND SIDE - STREET
PART NO. FS-Z900-2017-LHS-S

- 1 Remove upper engine mounting bolt - see location at **Fig. 1**
- 2 Assemble bolt through the aluminium bush adding CPBE-10-35 and place into correct position.
- 3 Tighten to 48Nm torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



Fig. 1




BULLET FRAME SLIDER - RIGHT HAND SIDE - STREET
PART NO. FS-Z900-2017-RHS-S

- 1 Remove upper engine mounting bolt - see location at **Fig. 1**
- 2 Assemble bolt through the aluminium bush adding CPBE-10-35 and place into correct position.
- 3 Tighten to 48Nm torque.
- 4 Slide bullet moulding onto aluminium bush.
- 5 Screw M6 bolt into front of bullet moulding hand tight.



Fig. 1



Bullet Frame Slider SET - STREET - Part No.: FS-Z900-2017-S

Engine Cover Set: EC-Z900-2017-SET-GBR

EC-Z900-2017-1-GBR, EC-Z900-2017-2-GBR, EC-Z900-2017-3-GBR

www.GBRacing.eu

DO NOT use these products unless you agree to our Terms & Conditions, as shown on our paperwork and website. If you do not agree, please return the product(s) to your dealer for a refund.